

CONCISE DETAILS OF RECEIVERS, Types R.1155, R.1155A, B, C, D, E, F, L, M, and N

Purpose of Equipment ... Designed for use in aircraft with transmitters of the T.1154 class. Also used in some A.S.R. launches, radio vehicles, and ground installations. Provides communications and direction-finding facilities.

Type of Wave ... C.W., M.C.W., and R.T.

Frequency Range	...	18.5 Mc/s to 3.0 Mc/s		<i>Types R.1155L and N only</i>	
	...	1,500 kc/s to 600 kc/s			18.5 Mc/s to 600 kc/s
	...	500 kc/s to 75 kc/s			500 kc/s to 200 kc/s

All versions use an I.F. of 560 kc/s

Maximum Sensitivity ... Input of 10 micro-volts at 210 kc/s gives output in excess of 50 milliwatts
Input of 9 micro-volts at 16 Mc/s gives an equivalent output

Selectivity ... Approximately 4 kc/s to 6 kc/s total bandwidth for 6 db attenuation

Output Impedance ... 5,000 ohms

Valves	Function	Description	Type	Stores Ref.
			Visual D/F switching	Two triode-hexodes	V.R.99A	10E/757
			R.F. amplifier	Variable-mu pentode	V.R.100	10E/278
			Frequency-changer	Triode-hexode	V.R.99	10E/277
			I.F. amplifier	Two variable-mu pentodes	V.R.100	10E/278
			A.V.C. and B.F.O.	Double diode triode	V.R.101	10E/280
			Speech diode, visual meter limiter and output	Double diode triode	V.R.101	10E/280
			Visual meter switching	Double triode	V.R.102	10E/279
			Tuning indicator		V.I.103	10E/305

Power Input ... Omni and A.V.C. approx. 45 watts
Visual D.F. approx. 50 watts

Power Output ... Max. 200 milliwatts into 5,000 ohms impedance

Stores Ref. ... R.1155, 10D/98; R.1155A, 10D/820; R.1155B, 10D/13045; R.1155C, 10D/1105; R.1155D, 10D/1331; R.1155E, 10D/1332; R.1155F, 10D/1333
R.1155L, 10D/1477; R.1155M, 10D/1597; R.1155N, 10D/1667

Approx. Overall Dimensions		<i>Length</i>	<i>Width</i>	<i>Height</i>
		16 $\frac{7}{8}$ in. ...	9 $\frac{3}{8}$ in. ...	11 $\frac{1}{8}$ in.

Weight ... Aluminium versions approx. 26 lb.
Steel versions approx. 32 lb.

Associated Equipment ... Transmitters, T.1154 series
Resistance units, types 47 and 52 and 52A
Aerial switch unit, type J
Visual indicator, type I
Impedance matching units, type 12, 13 or 15
Power units, types 32, 32A, 32B, 33, 33A, 33B, 34, 34A, 35, 35A, 114, 115, 268, and 380

September, 1947

CHAPTER 2

RECEIVERS, Types R.1155, R.1155A, B, C, D, E, F, L, M, and N

LIST OF CONTENTS

	<i>Para.</i>
Introduction	1
Facilities	2
Power supplies	3
Aerials	5
General description	6
Frequency range switch	7
Master switch	8
Communications circuits R.1155 and R.1155D—	
Aerial connections	10
R.F. amplifier stage	11
Frequency-changer stage	13
I.F. stages	16
Detector and output stages	17
Manual volume control	19
Automatic volume control	22
Beat frequency oscillator	27
Tuning indicator	28
Communications circuits, other versions—	
R.1155A, E, and M...	30
R.1155B and F	32
R.1155C	33
R.1155L and N	34
The direction-finding circuits	36
General principles	38
L.F. oscillator for D.F. switching	40
Aerial switching	41
Visual indicator switching	43
Meter amplitude	46
The diode limiter valve	48
Visual indicator balancing circuit	50
Visual sense determination	52
Aural D.F.	53
Constructional details	54
Front panel controls	55
Chassis layout	61
Installation	66
Receiver position	67
Power unit position	68
Aerial switch position	69
D.F. loop aerial and impedance matching	70
Fixed aerial input	76
The visual indicator, type I	77
Setting up the D.F. loop	79
Loop centre tap	80
Navigator-operated receivers	82
Power units	88
Operation	89
Controls	91
Setting up heterodyne oscillator	93
Back-tuning	94
Normal communication	96
D.F. bearings using visual indicator	97
Homing, using visual indicator	100
Aural D.F.	104
Precautions and servicing—	
Ground testing	107
Starter trolley batteries	111
Visual indicator	112
Trouble location	114
Test apparatus	115
Valve data	116
Valve identification	117
Valve replacements	118
Removal of B.F.O. valve	119
Prevention of frequency drift	120
Alignment of incorrectly calibrated receivers	121
Periodic inspections	126
Associated equipment	Appendix 1
List of principal components...	Appendix 2

LIST OF ILLUSTRATIONS

	<i>Fig.</i>
Receiver R.1155N	1
Schematic diagram	2
R.1155 and R.1155D circuit diagram with modifications for R.1155A, R.1155E, and R.1155M	3
R.1155B and R.1155F circuit diagram	3A
R.1155L and R.1155N circuit diagram	4
Simplified communications circuit	5
I.F. response curve	6
A.F. filter characteristics	7
Biasing and feed arrangements	8
Input/output characteristics	9
Simplified visual D.F. circuit	10
A.F. oscillator switching circuit	11
Visual indicator switching circuit	12
Simplified visual indicator switching circuit	13
Polar diagrams	14
R.1155 chassis, upper deck	15
R.1155 chassis, underside	16
Components location diagram	17
R.1155B chassis, upper deck	18
R.1155B chassis, underside	19
Valve connections	20
Typical installation diagram	21
Plug, type 209	22
Trouble location chart—Communications circuits	23
Trouble location chart—D.F. Switching circuits	23A
The impedance matching units, types 12, 13, and 15	24
Visual indicator, type 1	25




FIG. 1.—RECEIVER R.1155N