

WIRELESS SET NO. 19

FIRST ECHELON WORK

FITTING OF METERS OF UK MANUFACTURE TO CDN SETS

1. *Items affected:*

Wireless sets No. 19 Mk II Cdn.

2. In certain instances it has been found necessary to mount meters of UK manufacture in Canadian sets. This should only be done when the Canadian meters are not available.

3. In order to mount these meters one of each of the following parts are required:—

Rings, brass, $2\frac{3}{4}$ -in outside dia, $2\frac{3}{32}$ -in inside dia x $1/16$ -in thick.

Clips, retaining, No. 8 (ZN 2155).

Tubing, rubber, $\frac{1}{8}$ -in x 7-in (ZA 15062). This rubber is to be used as a washer.

In lieu of the brass ring, an ebonite ring may be made from $\frac{1}{8}$ -in stock.

4. The parts will be assembled in the following order: meter, rubber washer, brass or ebonite washer, panel, retaining clip. It may be found that an additional thickness of brass washer is required in certain installations.

5. The meter is electrically the same and may be connected normally.

END